

**Fig. 1**





Fig. 2

Fig. 3



Status No:	LEDs	Lit	Blinking	Out	Display	Meaning
220	R			X	Green	OK
	G	X			- Lit	
230	R	X			Red	Error from Static Test
	G			X	- Lit	
240	R	X			Orange	Error from Dynamic Test
	G	X			- Lit	
250	R		X		Red	Long Time without Contact
	G			X	- Blinking	
260	R			X	Green	Key not Entered
	G		X		- Blinking	
270	R		X		Orange	Suspect
	G		X		- Blinking	
280	R	X			Red Lit	Temperatur zu hoch
	G		X		Orange Blinking	
290	R		X		Green Lit,	Battery Replacement needed
	G	X			Orange Blinking	

Fig. 9




Fig. 4





Fig. 5



**Fig. 10**




Fig. 6




Fig. 7




Fig. 8a




Fig. 8b




Fig. 11




Fig. 12




Fig. 13a

Fig. 13b